PAIRING & RECONNECTING YOUR



WOMBAT PINE PRO KEYBOARD

- RADIO FREQUENCY (RF)
- BLUETOOTH



PAIRING YOUR WOMBAT KEYBOARD VIA RADIO FREQUENCY (RF)



1 CHECK THE BATTERY CHARGE

- On the underside of the keyboard, turn the switch to the On position.
- If the three LEDs blink once, the internal lithium battery is charged and ready.
- If the LEDs do not blink, the keyboard must be plugged in via USB cable and charged for a minimum of 5 hours before connecting wirelessly.



Add the Type A-to-Type C adapter to the top of the USB-A receiver.

Plug into your USB-C computer port.



USB-A USERS

Plug the USB-A receiver into the USB-A port of your computer.





PAIRING YOUR WOMBAT KEYBOARD VIA RADIO FREQUENCY (RF)



TO PAIR THE RF WIRELESS RECEIVER, PRESS & HOLD FN +



FOR 3 SECONDS

- Please note our RF receivers are generally pre-paired with our keyboards at the factory.

 In the event your receiver and keyboard are not linked, press and hold Fn + 1 for three seconds.
- Once paired successfully, the three LEDs will blink, and you may begin typing.







RECONNECTING YOUR WOMBAT KEYBOARD VIA RADIO FREQUENCY (RF)



TO RECONNECT THE ALREADY-PAIRED RF WIRELESS RECEIVER, ENSURE THE

BATTERY IS IN THE ON POSITON AND PRESS FN +



• Once reconnected successfully, the three LEDs will blink once, together, and you may begin typing.







PAIRING YOUR WOMBAT KEYBOARD VIA BLUETOOTH





• If any Bluetooth setup dialog boxes are open, close them before proceeding with pairing.

2 CHECK THE BATTERY CHARGE


Connect up to three devices to your keyboard via Bluetooth.

Pair your first device:



• The corresponding, leftmost LED will blink once, then all three LEDs will blink together.









PAIRING YOUR WOMBAT KEYBOARD **VIA BLUETOOTH**

CONNECT TO BLUETOOTH



Wombat keyboard is connected and ready for typing.



Cancel

INSTRUCTIONS

REPEAT THE SEQUENCE FOR IF YOU WISH TO CONNECT THE KEYBOARD TO OTHER HOSTS





RECONNECTING YOUR WOMBAT KEYBOARD VIA BLUETOOTH



RECONNECT TO A PAIRED COMPUTER HOST

- Ensure the battery has charge and the switch is in the On position.
- Press Fn + B1, or B2, or B3 once and wait for the corresponding LED to blink once.







Note: The keyboard must be paired whenever connecting to a new computer.



KEY SOURCE INTERNATIONAL





